

Expanded Gasket Placement Technique (EGP)

How to Stop Stubborn Leaks ...with AV-202 and Oakum

STEP-BY-STEP PROCEDURES TO GET RESULTS

Clean the Crack

Using water, flush out crack, joint or hole of any loose debris and foreign material.

Cut the Oakum

Cut oakum to meet size requirements of cracks, joints or holes.

Place Oakum in Pail

Place the oakum pieces into a heavy-duty plastic bag or clean pail.

Don't Forget Personal Protection

Put on PPE now - safety glasses and gloves.

Pour AV-202 Into Pail

Pour enough AV-202 into pail to cover oakum. Let oakum soak long enough to thoroughly saturate.

Place Oakum

With safety gloves on, insert saturated oakum into active leak.

Work Into Crack

Use a blunt instrument, such as a screwdriver or wooden blade, to drive oakum farther into the leaking area.

Cured Oakum

Soaked oakum serves as a gasket and swells to shutdown gushing leak. Flexible cure is long-lasting.

Unused Product

For unused portion of AV-202, wipe container threads clean of material, re-apply cap, and dispose of safety gloves.



For more information about AV-202 or the EGP Technique, call 800.877.2570 or visit www.AvantiGrout.com for videos, animations, and tech data sheets.

AVANTI Helping You Move Forward